### **Environmental Protection Agency**

test, use the following steps to precondition a canister and attach it to your engine:

- (1) Use a canister and plumbing arrangement that represents the in-use configuration of the largest capacity canister in all expected applications.
- (2) Precondition the canister as described in 40 CFR 86.132-96(j).
- (3) Connect the canister's purge port to the engine.
- (4) Plug the canister port that is normally connected to the fuel tank.
- (g) This paragraph (g) defines the components that are considered to be part of the engine for laboratory testing. See §1065.110 for provisions related to system boundaries with respect to work inputs and outputs.
- (1) This paragraph (g)(1) describes certain criteria for considering a component to be part of the test engine. The criteria are intended to apply broadly, such that a component would generally be considered part of the engine in cases of uncertainty. Except as specified in paragraph (g)(2) of this section, an engine-related component meeting both the following criteria is considered to be part of the test engine for purposes of testing and for stabilizing emission levels, preconditioning, and measuring emission levels:
- (i) The component directly affects the functioning of the engine, is related to controlling emissions, or transmits engine power. This would include engine cooling systems, engine controls, and transmissions.
- (ii) The component is covered by the applicable certificate of conformity. For example, this criterion would typically exclude radiators not described in an application for certification.
- (2) This paragraph (g)(2) applies for engine-related components that meet the criteria of paragraph (g)(1) of this section, but that are part of the laboratory setup or are used for other engines. Such components are considered to be part of the test engine for preconditioning, but not for engine stabilization. For example, if you test your engines using the same laboratory exhaust tubing for all tests, there would be no restrictions on the number of test hours that could be accumulated with the tubing, but it would

need to be preconditioned separately for each engine.

[79 FR 23772, Apr. 28, 2014]

#### § 1065.410 Maintenance limits for stabilized test engines.

- (a) After you stabilize the test engine's emission levels, you may do maintenance as allowed by the standard-setting part. However, you may not do any maintenance based on emission measurements from the test engine (i.e., unscheduled maintenance).
- (b) For any critical emission-related maintenance—other than what we specifically allow in the standard-setting part—you must completely test an engine for emissions before and after doing any maintenance that might affect emissions, unless we waive this requirement.
- (c) If you inspect an engine, keep a record of the inspection and update your application to document any changes that result. You may use any kind of equipment, instrument, or tool to identify bad engine components or perform maintenance if it is available at dealerships and other service outlets.
- (d) If we determine that a part failure, system malfunction, or associated repairs have made the engine's emission controls unrepresentative of production engines, you may no longer use it as an emission-data engine. Also, if your test engine has a major mechanical failure that requires you to take it apart, you may no longer use it as an emission-data engine.
- (e) If we determine that a part failure, system malfunction, or associated repairs have made the engine's emission controls unrepresentative of production engines, you may no longer use it as an emission-data. Also, if your test engine has a major mechanical failure that requires you to take it apart, you may no longer use it as an emission-data engine.

[70 FR 40516, July 13, 2005, as amended at 73 FR 37314, June 30, 2008; 79 FR 23773, Apr. 28, 2014]

## § 1065.415 Durability demonstration.

If the standard-setting part requires durability testing, you must accumulate service in a way that represents

#### § 1065.501

how you expect the engine to operate in use. You may accumulate service hours using an accelerated schedule, such as through continuous operation or by using duty cycles that are more aggressive than in-use operation, subject to any pre-approval requirements established in the applicable standard-setting part.

- (a) Maintenance. The following limits apply to the maintenance that we allow you to do on an emission-data engine:
- (1) You may perform scheduled maintenance that you recommend to operators, but only if it is consistent with the standard-setting part's restrictions
- (2) You may perform additional maintenance only as specified in §1065.410 or allowed by the standard-setting part.
- (b) Emission measurements. Perform emission tests following the provisions of the standard setting part and this part, as applicable. Perform emission tests to determine deterioration factors consistent with good engineering judgment. Evenly space any tests between the first and last test points throughout the durability period, unless we approve otherwise.

[70 FR 40516, July 13, 2005, as amended at 73 FR 37315, June 30, 2008]

# Subpart F—Performing an Emission Test Over Specified Duty Cycles

#### § 1065.501 Overview.

- (a) Use the procedures detailed in this subpart to measure engine emissions over a specified duty cycle. Refer to subpart J of this part for field test procedures that describe how to measure emissions during in-use engine operation. This section describes how to:
- (1) Map your engine, if applicable, by recording specified speed and torque data, as measured from the engine's primary output shaft.
- (2) Transform normalized duty cycles into reference duty cycles for your engine by using an engine map.
- (3) Prepare your engine, equipment, and measurement instruments for an emission test.

- (4) Perform pre-test procedures to verify proper operation of certain equipment and analyzers.
  - (5) Record pre-test data.
- (6) Start or restart the engine and sampling systems.
- (7) Sample emissions throughout the duty cycle.
  - (8) Record post-test data.
- (9) Perform post-test procedures to verify proper operation of certain equipment and analyzers.
  - (10) Weigh PM samples.
- (b) Unless we specify otherwise, you may control the regeneration timing of infrequently regenerated aftertreatment devices such as diesel particulate filters using good engineering judgment. You may control the regeneration timing using a sequence of engine operating conditions or you may initiate regeneration with an external regeneration switch or other command. This provision also allows you to ensure that a regeneration event does not occur during an emission test.
- (c) An emission test generally consists of measuring emissions and other parameters while an engine follows one or more duty cycles that are specified in the standard-setting part. There are two general types of duty cycles:
- (1) Transient cycles. Transient duty cycles are typically specified in the standard-setting part as a second-by-second sequence of speed commands and normalized torque (or power) commands. Operate an engine over a transient cycle such that the speed and torque of the engine's primary output shaft follows the target values. Proportionally sample emissions and other parameters and use the calculations in subpart G of this part to calculate emissions. Start a transient test according to the standard-setting part, as follows:
- (i) A cold-start transient cycle where you start to measure emissions just before starting an engine that has not been warmed up.
- (ii) A hot-start transient cycle where you start to measure emissions just before starting a warmed-up engine.
- (iii) A hot running transient cycle where you start to measure emissions after an engine is started, warmed up, and running.